



!CROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS !963-A

THE RESIDENCE OF THE PARTY OF T

Communications Research Centre

AD-A173 709

EHF SHELF POWER MONITOR AND CONTROLLER

by

R. Addison



This work was sponsored by the Department of National Defence, Chief of Research and Development Branch, Task No. 32A.

Government of Canada Department of Communications

Gouvernement du Canada Ministère des Communications CRC REPORT NO. 1399 OTTAWA, SEPTEMBER 1985

This document has been approved by public release and subs its distribution is unlimited.

Canadä

86 11 4 094

COMMUNICATIONS RESEARCH CENTRE

DEPARTMENT OF COMMUNICATIONS CANADA

EHF SHELF POWER MONITOR AND CONTROLLER

by

R. Addison*

(Radar and Communications Technology Branch)

Asses			_				
	ssion Fo	70					
NTIS	GRALI	A	_				
DTIC	TAB	否					
Unanr	nounced	ñ					
Just	ficatio	n					
ļ			_				
Ву							
Distr	Distribution/						
Availability Codes							
	Avail a	and/or	-				
Dist	Special						
	1 1		Í				
01			-				
47	1		1				
			1				



CRC REPORT NO. 1399

September 1985 OTTAWA

This work was sponsored by the Department of National Defence, Chief of Research and Development Branch, Task No. 32A.

* With DREO/ED but on secondment to the Space Systems Directorate of CRC.

This document has been approved for public release and sales in distribution to unlimited, provided

CONTENTS

		F	PAGE
1	INTRODU	CTION	. 1
2	HARDWAR	E	. 4
2.1	EXIST	ING HARDWARE	. 4
2.1.1	Pro	blems With The Old System	. 4
2.1.2		nges Implemented	
2.2	EHE SI		. 7
2.2.1		lf Computer	_
2.2.2	Sne	cial Purpose Parallel I/O And Switch Driver	
2.2.2	Sper	•	Ω
2.2.3	Boa.	rd	
2.3	COMMA	ND AND DISPLAY PANEL	. 9
2.3.1	Ins	tallation And Configuration Information	. 9
2.3.2	Fro	nt Panel Operation	. 9
2.3.3	Com	munications Board	10
2.3.4	Dis	play Board	11
2.3.5		r Panel And Power Supply	12
3		E	12
		AM CODING METHODS	12
3.1 3.2		AND COMMAND SELECTION	13
	MODE .	AND COMMAND SEDECTION	13
	DATA	ACQUISITION AND CONVERSION	
3.4	DATA	AND STATUS DISPLAY	14
4	CONCLUS	ION	14
	_		
APPENDIX	(A	MICROWAVE DETECTOR CALIBRATION	
APPENDIX	K B	SPECIAL PURPOSE PARALLEL I/O BIT ASSIGNMENTS	S
APPENDIX	{ C	KEYPAD CODES	
APPENDIX	מ ז	COMMUNICATIONS PROTOCOL	
AL LUNDIA		COMMONICATIONS INSTSEED	
APPENDIX	2 TD	SPECIAL PURPOSE PARALLEL I/O AND SWITCH DRI	77ED
APPENDIA	\ E	SPECIAL PURPOSE PARALLEL 1/O AND SWITCH DRI	VLK
APPENDIX	(F	COMMUNICATIONS BOARD SCHEMATICS	
APPENDIX	{ G	DISPLAY BOARD SCHEMATICS	
APPENDIX	СН	REAR PANEL AND POWER SUPPLY SCHEMATICS	
	-		
APPENDIX	۲т	ROM PROGRAM LISTING	

LIST OF FIGURES

			Page
Fig.	1.1	CRC Ground Terminal	2
Fig.	1.2	EHF Ground Terminal Block Diagram	3
Fig.	2.1	Front Panel	5
Fig.	A1.1	LO Detector Calibration	16
Fig.	A1.2	Pi Detector Calibration	17
Fig.	A1.3	Po Detector Calibration	18
Fig.	A1.4	Pr Detector Calibration	19
Fig.	E1	Special Purpose Parallel I/O and Switch Driver Board Block Diagram	26
Fig.	F1	Communications Board Layout	28
Fig.	F2	Communications Board Schematic	29
Fig.	G1	Display Board Layout	31
Fig.	G2	Display Board Schematic	32
Fig.	H1	Rear Panel Layout	34
Fig.	Н2	Rear Panel and Power Supply Schematic	35

1 INTRODUCTION

In 1981, the Military Satellite Communications (MILSATCOM) section of Communications Research Centre (CRC) installed an Extremely-High Frequency (EHF) ground terminal to use the Lincoln Experimental Satellites LES 8 and LES 9. The antenna was put on top of the elevator shaft and covered with a radome. See Figure 1.1, CRC EHF Ground Terminal. The shelf on the back of the dish was used to house the Radio Frequency (RF) equipment. The Intermediate Frequency (IF) and baseband equipment was installed in a lab three floors below.

It was desired that the shelf be configurable to various operating modes. The possible choices were: LES 8 or LES 9 satellites, receive only or transmit/receive, and dish or horn antenna on the satellite (the antennas had slightly different frequencies).

The distance between the two installations suggested remote control of the shelf hardware. Such a system was built to monitor power levels and to control the operating modes of the shelf. This enabled rapid diagnosis of problems and quick changes of configuration without leaving the lab.

This document first explains the hardware used in the monitoring and controlling system. This includes the previously existing system, the shelf computer and the display panel. See Figure 1.2, EHF Ground Terminal Block Diagram for the system diagram.

Finally, the software developed for the shelf computer will be covered. The program listing is included as Appendix I, ROM Program Listing.




Fig. 1.1 CRC EHF Ground Terminal




Fig. 1.2 EHF Ground Terminal Block Diagram

2 HARDWARE

The hardware consists of the shelf computer that takes the measurements and controls the microwave switches, and a command and display panel located three floors below. See Figure 1.2, EHF Ground Terminal Block Diagram.

2.1 EXISTING HARDWARE

When the shelf was designed, provision was made for remote control, but no computer was installed. Instead, the modes were selected by Dual-In-Line (DIP) switches and Light Emitting Diodes (LEDs) indicated the position of the waveguide switches. To change modes, one had to climb to the dome and change the switches.


Later, an LSI 11 computer was incorporated to control the switches and to monitor the power levels. An analog acquisition board was built, as well as a display panel. The system was controlled by a terminal that was co-located with the display panel in the lab.

The previous display panel consisted of a display board and a communications board. The display board showed five three-digit power levels, each with a LED to indicate valid (green) or invalid (flashing red) data. The communications board intercepted all data to the terminal and passed on the data that was not addressed to the display panel.

2.1.1 Problems With The Old System -

The previous system was not reliable. A redesign of the system was required to fix the following problems:

- One of the analog signals was low enough to be affected by the noise of the analog acquisition system. This could be corrected by decreasing the noise level of the existing board or by using a different board with better characteristics.
- 2. The system required a VT100 Terminal to control the operation of the shelf. This VT100 had to be dedicated to a task which took about five minutes per day.



FRONT PANEL

Fig. 2.1 Front Panel

- 3. The existing communication board was unreliable and required periodic maintenance. The communication protocol was not robust and could cause the panel to enter illegal states.
- 4. The panel powered up displaying erroneous data.

2.1.2 Changes Implemented -

The following changes were made to fix the above mentioned problems:

- 1. To solve the noise problem, a new analog acquisition board was used. This board had the advantage of programmable gain, differential inputs and a more mature design. These characteristics served to reduce the noise effects to a tolerable level.
- 2. A keypad was added to the front panel to command the different modes of operation. See Figure 2.1, Front Panel. The LEDs used to indicate valid/invalid data on the display panel were reassigned to system status LEDs. This enabled the VT100 to be freed for other projects.
- 3. The entire communication board was redesigned. The new design amounted to significant parts reduction and improved reliability. The communications protocol was also changed to increase the robustness. The protocol is further described in Appendix D, Communications Protocol.
- 4. A power up reset was implemented to ensure that the displays were initialized. Also a LED minus sign was added to improve the appearance of negative power levels.
- 5. A rear panel containing power supplies and external connectors was added to the display panel.

2.2 EHF SHELF HARDWARE

The control hardware on the shelf is comprised of the shelf computer, its parallel Input/Output (I/O) board with switch drivers, and waveguide switches. Also controlled are several coaxial switches and some power relays. To sense the power levels, there are microwave diode detectors. The calibration curves of the detectors can be found in Appendix A, Microwave Detector Calibration.

2.2.1 Shelf Computer -

The shelf computer contains four boards. They are:

- 1. KD11-HA LSI 11/2 Processor Board with EIS and FIS
- 2. MXV11-A Multifunction Board
- 3. ADV11-C Analog Input Board
- 4. Special Purpose Parallel I/O and Switch Driver Board

With the exception of the special purpose parallel I/O Board, all the boards are standard Digital Equipment Corporation (DEC) boards and are documented in the Microcomputers and Memories Manual, and the Microcomputer Interfaces Manual, both available from DEC. The parallel I/O board is detailed in the next section.

The LSI 11/2 processor supports the standard PDP 11 instruction set. The Extended Instruction Set (EIS) gives the processor fixed point multiply and divide capability. The four basic floating point operations are provided by the Floating point Instruction Set (FIS).

The MXVII-A Multifunction board provides the minimum support required by the processor. It contains 16K words of Random Access Memory (RAM) and 4K words of program Read Only Memory (ROM). Also on board are two serial ports, one of which is used to communicate with the display panel. The other serial port is unused.

The ADVII-C Analog Input board can sample up to eight channels using differential inputs with 12 bit resolution. Only five of the eight channels are used in this application. The important feature of this board is the programmable gain (1X, 2X, 4X or 8X) which enables the low level signals to be accurately digitized.

2.2.2 Special Purpose Parallel I/O And Switch Driver Board -

For a block diagram, see Appendix E, Special Purpose Parallel I/O and Switch Driver Board Block Diagram.

The special purpose parallel I/O and switch driver board was built in the CRC MILSATCOM lab to control the microwave switches and to display their positions. Initially, the computer control of this board was bypassed. Front panel switches provided the control. When the processor was installed, the board was designed to respond to computer control as well.

The LSI 11 Q-BUS interface of this board looks like two 16 bit parallel ports - one input (read only) and one output (read or write). The input bits are TTL levels indicating the positions of the switches, and status of the Travelling Wave Tube (TWT) amplifier. The output bits are converted to appropriate levels to drive the switches and relays. For bit assignments, see Appendix B, Special Purpose Parallel I/O Bit Assignments.

There are eight latching waveguide switches which, when switching, require two amps of current. To have all eight switch at once would require a hefty power supply. In order to minimize the power requirements, only one switch is changed at a time. A sequencer is used so that within two seconds all switches can be changed. This sequencing through the switches is done automatically by circuitry on the board and is transparent to the user.

2.2.3 Communications With Panel -

Command and display information are passed by serial link between the shelf and the display panel. The shelf communicates by the console port of MXVII multi-function board in the LSI ll. The character-serial (asynchronous) signal passes through a Gandalf LDS 120 modem, down three floors, and through another LDS 120. The signal then enters the AY-3-1015 Universal Asynchronous Receiver/Transmitter (UART) on the communication board.

The characteristics of the asynchronous serial link are: 1200 baud data rate, 8 bits, no parity, 1 stop bit and RS232-C signal levels. All control lines are held in the active state.

For information on panel-to-shelf communications, see Appendix C, Keypad Codes.

For detailed information on the shelf-to-panel communications, see Appendix D, Communications Protocol.

2.3 COMMAND AND DISPLAY PANEL

The command and display panel consists of five numeric displays, five status displays, an AC switch and indicator LED, and a command keypad.

Three decimal digits make up each numeric display. The displays show TWT output SWR, TWT output power, TWT input power, LO power for upconverter, and LO power for downconverter.

The status displays are green LEDs below the numeric displays. They indicate TWT AC power on, TWT ready, TWT RF switched on, all wavequide switches set, and system ready.

The command keypad functions are described in Appendix C, Keypad Codes.

2.3.1 Installation And Configuration Information -

The only configurable option is the baud rate of the communications board. The switch settings are detailed in Appendix F, Communications Board Schematics.

The RS232-C interface on the back looks like a terminal (DTE). Both Request To Send (RTS pin 4) and Data Terminal Ready (DTR pin 20) are pulled high. The interface is as detailed in Section 2.2.3, Communications with Panel.

2.3.2 Front Panel Operation -

For a diagram of the front panel, see Figure 2.1, Front Panel.

Upon power up, all displays are set to zero and the status LEDs are turned off. The default mode is LES 8, receive only, using the dish. The LO power levels are monitored and the TWT is off.

To change modes, push the appropriate mode button (any of the eight LES 8/9 buttons or the local loopback) followed by the GO button. If the wrong button is pushed, press CLR KEY and start again.

If a receive only mode (green buttons) is chosen, the TWT displays will show OFF. The waveguide switches will then be set. Successful setting of the switches will cause the SWITCHES SET light to go on. If, after a minute, the light is not on then there is a problem on the shelf. After the switches are set, the SYSTEM READY light should come on to indicate that the TWT and switches are all properly configured. The shelf is now ready for operation.

If a transmit mode (pink buttons) is chosen, all displays will become active. As with receive only mode, the SWITCHES SET light indicates that the waveguide switches are properly set. The transmit mode requires the Hughes TWT amplifier which needs a five minute warm up period. After the switches are set, the TWT is turned on (AC ON light). If it was in standby (AC ON, TWT READY already lit), it will be ready right away, otherwise there is a five minute wait for the READY light. When it is ready, the RF is switched on. Now the system is properly configured and ready to operate, so the SYSTEM READY light is turned on.

When switching into a receive only mode after transmitting, the TWT is not turned completely off. Instead, it is put on standby. This is indicated by AC ON, READY lit and RF ON turned off. If it is desired to switch the TWT off from the standby mode, press the TWT OFF button. This will immediately turn off the TWT, but leave the system in the current mode.

All non-labelled keys on the keypad are inactive and ignored.

2.3.3 Communications Board -

For schematics, see Appendix F, Communications Board Schematics.

The heart of the communications board is the AY-3-1015D UART. This integrated circuit receives characters from the keypad encoder and transmits them serially to the shelf. It also receives the display information and routes the data to the display board. The baud rate is supplied by the K1135A Dual Baud Rate Generator. The rate used is 1200 baud, but the chip is DIP switch configurable for 16 different baud rates. Only one channel of the generator is required, the other is unused.

The keypad, found on the front panel, is a four by four switch matrix. This is scanned by the 74C922 Keyboard Encoder which generates four bit codes for each key press. These codes are strobed into the UART using a 74LS221 Dual Monostable Multivibrator (one-shot) to shape the strobe. The UART takes in

eight bits but the keyboard encoder only generates four. This leaves four bits to be hardwired. The least significant bit (b0) is set to zero (thus only even keycodes are generated). The next four bits (b1 - b4) are connected to the keyboard encoder. The upper three bits (b5-b7) are set so that the keycodes generated start at decimal 64 (ASCII '0'). This ensures that all keycodes are printable ASCII characters.

When a break occurs, the Framing Error (FE) pin of the UART is asserted. This, combined with some gates, causes the High/Low Byte flip-flop to be reset at the end of the break. The High/Low Byte flip-flop is used to generate a strobe that latches the first byte in the High Byte latch. The flip-flop also generates a strobe for the display board that latches the entire word when the second byte is received.

The TTL signal levels to and from the UART are converted to RS232-C levels by the MC1488 Driver and by the MC1489 Receiver.

2.3.4 Display Board -

For schematics, see Appendix G, Display Board Schematics.

The display board contains the circuitry to demultiplex the display information and to display five 3-digit numbers. The information is latched on a signal from the communications board. The upper bit (b15) of the word from the latch is ignored. The next three significant bits (b12-b14) are routed to the most significant digit of the display cells. The bits (b8-b11) go to the middle digit of the display. The next four bits (b4-b7) go to the least significant digit of the display. The three bits (b1-b3) are interpreted as the display cell address. Valid values are 1 to 5. The least significant bit of the low byte (b0) is routed to the status light of the display cell.

Upon receiving a strobe from the demultiplexer, a display cell will latch the digits and the status bit. The latches drive TI 311 Hexadecimal displays. The status bit will cause the LED to turn green if set, and cause it to turn off if reset.

Also on this board is a 74LS121 Monostable Multivibrator to provide the power-up reset. This resets the 74LS373 Octal Latches used in the display cells.

For more information on the display cell addresses, see Appendix D, Communications Protocol.

2.3.5 Rear Panel And Power Supply -

For schematics, see Appendix H, Rear Panel and Power Supply Schematics.

On the rear panel is the DC power supply hardware and the DB25 connector for the RS232-C interface. The AC come in on a removable power cord, is fused and switched on the live wire, and then is connected to two DATEL power supply modules. The modules are the USM 5/5 (5V @ 5A) and the BPM 15/200 (+15V @ 200mA, -15V @ 200mA). The DC ground is connected to the third prong of the AC plug.

3 SOFTWARE

The program for the controlling computer, POWMON, is stored entirely in 4K words of ROM on the MXVII Multifunction Board. The source was written in PDP 11 assembler language using an RT 11 operating system.

In general, the design of the software was not limited by space, capabilities or time. The MXVII board can handle up to 8K words of ROM. The LSI II is a very powerful processor and was not required to use its full capabilities. Also, the displaying of the power levels is not a time critical task. In summary, the design of the power level monitoring system was without major constraints.

A program listing can be found in Appendix I, ROM Program Listing. This listing contains many comments that will complement the software description.

3.1 PROGRAM CODING METHODS

The original version of the program POWMON was almost exclusively written in MACROS. MACROS look similar to subroutines, but cause inline code to be generated at assembly time. These constructs are assembly language analogues of the ADA generics. Unfortunately, due to the limitations of the assembler, small changes in the program often caused assembler errors (this was due to the length limit on local symbol blocks). Another problem was that the program used almost all of the available 4K word ROM space (up to 8K words could be used, but the ROMs required would be more expensive and harder to program).

The difficulties incurred in updating the program forced a rewriting of the code. The major change was that many of the functions previously implemented by use of MACROs were done using subroutines. This had the advantage of decreasing the memory requirement and facilitating updates. MACROs are complex assembler structures and are not easy to interpret even for advanced programmers. The conversion to subroutines improved the readability of the code.

3.2 MODE AND COMMAND SELECTION

STATE OF THE PROPERTY OF THE PARTY OF THE PA

When a key is pressed on the front panel, an ASCII keycode is transmitted to the computer. The interrupt service routine then interprets this character. If a mode key was pressed, the associated mode pointer is saved in a memory location. If the CLR KEY was pushed, then this memory location is cleared. When the GO key is pressed, a flag is set to alert the main program to change modes. The TWT OFF key causes the previous mode to be reselected, but with the TWT turned off. All other keys are ignored.

The main program detects the flag set by GO or TWT OFF and takes appropriate action. For a transmit and receive mode, the microwave switches are set and the TWT is turned on. The program waits for the TWT to be ready before proceeding with normal monitoring. A receive mode selection puts the TWT into standby if it was on. It is turned off if the TWT OFF key was pressed. The microwave switches are set and then normal monitoring takes place.

3.3 DATA ACQUISITION AND CONVERSION

For each channel, the 'MON' MACRO invokes the 'MONSUB' subroutine. Given the channel number, the subroutine 'READ' selects the correct analog-to-digital scale and then polls the ADV11 Analog Input Board to get the value. Eight values are taken and averaged in subroutine 'MONSUB'.

These values are converted by direct table lookup in subroutine 'LOOKUP' to dBm power levels. The results are checked by 'CHECK' to ensure they are within design limits. If not, 'CHECK' turns off the TWT amplifier to protect it from damage. This is readily visible on the display as the TWT AC ON status light will go off.

The reflected power measurements are not used directly. The difference (in dB) between the output power and reflected power is used to calculate the SWR ratio by table lookup. This

SWR is checked to ensure it is within limits as specified by the Hughes TWT manual.

The lookup tables can be found in the end of the software listing of Appendix I, ROM Program Listing. The tables are graphically depicted in Appendix A, Microwave Detector Calibration.

3.4 DATA AND STATUS DISPLAY

After the values have been calculated, they are converted to BCD. When in receive only mode, the TWT power measurements are not displayed. The letters "OFF" are shown in the display to indicated that the TWT is off. The status bit and display address are tacked onto the word by subroutine 'ADR'. The status bits are stored in an array called 'LIGHTS', and are turned on by the MACRO 'LIGHT', off by the MACRO 'DARK'. The program continually loops through the data acquisition, conversion and display unless interrupted by a mode change command.

4 CONCLUSION

This system has been in operation in the final form since June 1983. During this time, it has performed as designed and successfully facilitated reconfiguration and trouble shooting of the EHF ground terminal.

One possible improvement would be to add a reset key to the keypad. When the program is waiting for the TWT to be ready, all mode changes are ignored. If one wants to changes the mode (maybe the wrong button was pressed), one has to wait the five minutes for the TWT to warm up. A reset key would bring the program out of this waiting loop.

Another improvement would be to enlarge the lookup tables to have finer steps in the numeric display. An alternate solution would be to use the existing tables to interpolate.

APPENDIX A

MICROWAVE DETECTOR CALIBRATION

ACCOUNT OF THE PROPERTY OF THE

There are five microwave detectors on the shelf. They measure:

1.	Downconverter Local Oscillator Power	12.380 GHz
2.	Upconverter Local Oscillator Power	12.580 GHz
3.	TWT Input Power	36.840 GHz
4.	TWT Output Power	36.840 GHz
5.	TWT Output Reflected Power	36.840 GHz

Though the LOs have slightly different frequencies, their calibration curves are identical. Thus, there is only one LO calibration required.

The four graphs, Figures Al.1 to Al.4, depict the lookup tables used in the software. They take into account all the coupling attenuation and give direct power levels based on the Analog to Digital conversion count. This count is proportional to the voltage put out by the detectors.




Fig. Al.1 LO Detector Calibration




Fig. Al.2 P_l Detector Calibration




Fig. Al.3 Po Detector Calibration




Fig. Al.4 Pr Detector Calibration

APPENDIX B

SPECIAL PURPOSE PARALLEL I/O BIT ASSIGNMENTS

The	output	port as	signments	are:	
bits	0-6	0 =	LES 8	l =	LES 9
bit	7	0 =	normal	1 =	loopback
bits	8-9	0 =	dish	1 =	horn
bit	10	0 =	LES 8	1 =	LES 9
bit	11	0 =	normal		loopback
bit	12		-una:	ssigned-	
bit	13	0 =	WJ AC of:	f = 1 =	WJ AC on
bit	14	0 =	TWT AC O	ff = 1 =	TWT AC on
bit	15	0 =	TWT RF O	ff 1 =	TWT RF on

To select LES 8 or LES 9 operation, all applicable bits must be set to the LES 8 or LES 9 mode and the loopback bits (b7 & b11) must be put to normal. To select local loopback, the LES 8/LES 9 bits (b0-b6 & b10) must be set to LES 8 and the loopback bits must be set to loopback.

Bit 13 turns on the Watkins-Johnson amplifier. Bit 14 turns on the Hughes Travelling-Wave Tube amplifier. The TWT RF (bl5) must be set in all modes that transmit.

The input port bit assignments are feedbacks from the switches for bits 0-13. Their interpretation is the same as the output port. Bit 14 indicates the TWT ready and bit 15 is unassigned.

APPENDIX C

THE RESERVE OF THE PROPERTY OF

KEYPAD CODES

Code(Decimal, ASCII)		Key			Meaning		
Mode Keys							
Diek	64, 66,		8	<-	(->	LES 8, Receive only, Dish LES 8, Transmit and receive,
Dish	68, 70,	D F	8	<-	< <	->	LES 8, Receive only, Horn LES 8, Transmit and receive,
Horn	-						·
	72, 74,	H J	9 9	<-	(->	LES 9, Receive only, Dish LES 9, Transmit and receive,
Dish							
	76, 78,	L N	9 9	<-	< <	- >	LES 9, Receive only, Horn LES 9, Transmit and receive,
Horn	80,						Local loopback mode
	,	_	<	(·\		
-unused-							
	82-8	36					Unallocated
Com	nand	Keys					
key	88,		GC)			Change mode to last pressed
<i>,</i>	90,	Z	CI	LR K	ΈY		Clear last pressed mode key
-unus	sed-						
	92						Unallocated
Comr	nand	Key					
	94,		TW	T O	FF		Turn off TWT (TWT is left in standby when not in
use)							-

The code (or its ASCII representation) is the byte generated by the UART and sent to the shelf when the key is pressed. Note that no odd numbered codes are generated and that all codes are printable ASCII characters.

Mode keys must be terminated with the GO key to take effect. Modes are either green (receive only mode) or pink (transmit/receive mode).

Command keys (all yellow keys) are acted upon immediately.

All unlabelled keys are inactive and ignored.

APPENDIX D

COMMUNICATIONS PROTOCOL

Each display consists of three BCD digits. This means that 12 bits are required for the numeric display. If one bit is assigned to the status light, that leaves three bits to address the display. Actually, only 11 bits are used for the numeric display. The most significant digit can only take on values 0 to 7.

Each display modification consists of four 8 bit bytes - high byte, low byte and then two guard bytes. The messages are interpreted as follows:

Middle digit (BCD encoded)
Most significant digit (3 bits only)
Ignored by communications board
Status light
Display address (1-5)
Least significant digit (BCD encoded)
all 1s
all 1s

One guard byte is necessary to allow the latch circuitry to return to initial state prior to the next update. The other byte is used to ensure an even number of bytes (for the High/Low Byte flip-flop).

STATES AND SECOND SECOND STREET, WINDERS SECOND SECOND SECOND SECOND SECOND SECOND SECOND SECOND SECOND SECOND

Prior to sending a set of five new values, a break is sent. This causes the communications board to reset the High/Low Byte flip-flop. If the an error in the communication line caused the flip-flop to be in the wrong state (expecting a high byte when a low one is being sent), this break ensures that the flip-flop starts at the proper state.


The display addresses used are as follows:

Address	Numeric Display	Status Light
5*	Down LO Power	SYSTEM READY
1	Up LO Power	SWITCHES SET
2	TWT Pi	TWT RF ON
3	TWT Po	TWT READY
4	TWT SWR	TWT AC ON

*Address 5 originally was address 0. When a break was transmitted, it would be interpreted as a zero word for address 0 which would clear the display cell. To circumvent this problem, that display cell was reassigned to address 5. In the software, references to address 0 are interpreted as references to address 5.

APPENDIX E

SPECIAL PURPOSE PARALLEL I/O AND SWITCH DRIVER BOARD BLOCK DIAGRAM



Special Purpose Parallel I/O and Switch Driver Board Block Diagram E Fig.

APPENDIX F

COMMUNICATIONS BOARD SCHEMATICS

Communications Board Components

Connectors:

- J4 Terminal block, 4 wide, DC power, from rear panel
- J6 8 pin socket, RS232 port, to rear panel
- J7 8 pin socket, keypad interface, to front panel
- J8 16 pin socket, parallel data, to display board
- J9 Quick release plug, power-up reset, from display board

Switches:

- S2 Keypad switch matrix, found on front panel
- S3 DIP switch, 4 wide, baud rate selector

Integrated Circuits:

- Ul MC1488P, RS232 line driver
- U2 MC1489P, RS232 line receiver
- U3 74LS221, Dual monostable multivibrators
- U4 74LS374, Octal latch
- U5 74C922, 16 key encoder
- U6 74LS74, Dual D flip-flops
- U7 74LS27, Triple 3-input NOR
- U8 74LS00, Quad 2-input NAND
- U9 AY-3-1015, UART
- U10 K1135A, Dual baud rate generator
- Ull MC7812CT, +12V regulator

Discrete Components:

- R1-R4 10k0hm, 1/4W
- C1-C8 C271K5, 270pF
- + other unlabelled resistors and capacitors on the schematics




Fig. Fi Communications Board Layout




Fig. F2 Communications Board Schematic

APPENDIX G

DISPLAY BOARD SCHEMATICS

Display Board Components

Connectors:

- J5 Terminal block, 2 wide, DC power, from rear panel
- 16 pin socket, parallel data, from communications J8

board

J9 Quick release plug, power-up reset, to comm. board

Integrated Circuits:

- U12 74LS374, Octal latch with tristate outputs
- Ul3 7404, Hex inverters
- Ul4 74LS374, Octal latch with tristate outputs
- U15 74LS138, 3 to 8 line decoder
- Ul6 74LS08, Quad 2-input AND Ul7 SE555N, Timer
- U18 7432, Quad 2-input OR
- U19 74121, Monostable multivibrator
- U20-U24 7400, Quad 2-input NAND
- U25-U29 74LS373, Octal latch with clear
- U30-U34 74LS373, Octal latch with clear

Display Elements:

- Red/Green bidirectional LEDs, indicate status L1-L5
- L6-L10 TIL311, Hexadecimal displays with logic
- L11-L15 TIL311, Hexadecimal displays with logic
- L16-L20 TIL311, Hexadecimal displays with logic
- Bar LED DIP, 2-wide, used as minus sign L21
- L22 Red LED, used as AC power indicator

Discrete Components:

- R5 1615-391G, Resistor DIP, 390 Ohms x 15, common pin
- 1413-331G, Resistor DIP, 330 Ohms x 13, common pin
- + other unlabelled resistors and capacitors on the schematics




Fig. Gl Msplay Board Layout




Fig. G2 Msplay Board Schematic

APPENDIX H

REAR PANEL AND POWER SUPPLY SCHEMATICS

Rear Panel and Power Supply Components

Connectors:

Contract Contract Statement

- J1 AC receptacle
- J2 DB25 female, for RS232 port, looks like a DTE
- J3
- Quick release plugs(2), to AC switch on front panel Terminal block, 4 wide, DC power, to communications J4 board
 - Terminal block, 2 wide, DC power, to display board **J**5
- 8 pin socket, for RS232 port, from communications J6 board

Switches:

Toggle switch, SPDT, for switching AC, on front panel Sl

Fuses:

F1 250V @ 1A, AC power

Power Supply Modules:

M1 USM-5/5, 5V @ 5A

M2 BPM-15/200, +/-15V @ 200mA




Fig. Hl Rear Panel Layout




Fig. H2 Rear Panel and Power Supply Schematic

APPENDIX I ROM PROGRAM LISTING

```
.TITLE POWMON - VERSION 1 REV04
                           29 Jun 83
;REV04 generated by Robin Addison
                                        29 Jun 83
                          ;CHANGES: 1. Use the AXV-11 board for
                                  A/D and use a lookup table
                                  to produce dBm.
                                  2. Use modified interface
                                  front panel and respond to
                                  keypad.
                                  3. Rewrite of main code to
                                  improve program flow.
                                  4. Reformatting of code and
                                  comments to improve readability.
          ***************
                          ; REVO3 GENERATED BY DAVE SIM 1983-05-03
                          ; CHANGES: LEAVE TWT AC POWER ON AFTER
                                  FIRST TIME SELECTED.
                                  CNTL/R CLEARS THIS FUNCTION
                                  NEXT TIME RX MODE SELECTED.
;REV02 GENERATED BY DAVE SIM 1983-04-29
                          ;CHANGES: REMOVE SOME JUMPS IN FLOW
                                 ADD MORE FEEDBACK MESSAGES
                          ;REV01 GENERATED BY DAVE SIM 1983-04-18
                          ; ADDITIONS: TRAP CATCHERS
                                   STACK SETUP
                                   INTERRUPT SVC FOR KBD
                                   TRANSLATE DEFAULTS TO LESS
                                      DISH CROSSLINK RECEIVER
```

property tracertal processing concess consists concer consists process processes processes and

; This file contains source code for the interactive power level; monitoring system. Information on the desired mode of operation is entered; via the keypad. The program sets various switches to achieve that mode,; checks these settings and changes over to power monitor mode. In this mode; of operation a display is updated with five items:

- (1) TWT Output Power
- (2) TWI Input Power
- (3) TWT VSWR
- (4) LO Up Power
- (5) LO Down Power

" Writer: Mike Colven "
" For: EHF SatCom "
" Date: Sept. 82

```
DECLARATIONS
        = %4
POWER
OFFPOW = 377
NOMASK = 0
                                 ; PATCH TO 130000 FOR TESTING
SWREG
        = 170000
FBREG
        = 170002
                                 ; PATCH TO 130000 FOR TESTING
DISP
        = 177566
                                 :Communications interface -
TXCSR
        = 177564
                                 ; Tx to display panel
        = 177566
TXBUF
                                 ; Rx from keypad
RXCSR
        = 177560
        = 177562
RXBUF
                                 ;Analog to digital converter
ADCSR
        = 170400
        = 170402
ADBUF
DAABUF = 170404
DABBUF = 170406
ADGO
        = 1
SCALE2 = 4
SCALE8 = 14
RX
        = 000000
                                 ;Switch register definitions
TX
        = 160000
TRANLA = 004200
DISH
        = 000000
HORN
        = 001400
LES8
        = 000000
LES9
        = 002177
TWIBIT = 160000
TWIRF
        = 100000
TWIAC
        = 040000
TWTRDY = 040000
MOOM
        = 020000
                INITIALIZE TRAP AND INTERRUPT AREAS
        .ASECT
                = 4
        .WORD
                                         ;Time out
                .+2,HALT
        .WORD
                .+2,HALT
                                         ;Reserved
                                         ;BPT
        .WORD
                .+2,HALT
        .WORD
                .+2,HALT
                                         ;IOT
                                         ;Power fail
        .WORD
                1000,340
                                         ;Console
                = 60
        .WORD
                KBINIR, 340
                                         ;Clock
                = 100
        .WORD
                .+2,RTI
        .CSECT
```

; ;	MACRO DEFINITIONS				
, MACRO	CLR TST BGE	POWER,?STEP R1 POWER STEP	;Converts the binary POWER to a ; BCD representation		
STEP:	NEG COUNT SHFT4 COUNT	POWER POWER, #100. R1 POWER, #10.	;Find the hundreds ;Find the tens		
.ENDM	SHFT4 COUNT MOV	R1	;Find the ones		
·ENLA					
.MACRO LOOP:	COUNT CMP BLIT INC SUB BR	A,B,?LOOP,?ST A,B ST Rl B,A LOOP	; Finds the number of Bs in A ; ie: (R1) = INT(A/B)		
ST: .ENDM	DK	IDOP			
.MACRO	DARK MOV ASL CLR MON	X #X,RO RO LIGHTS(RO) X	;Macro to turn off light X		
.ENDM		•			
.MACRO	LIGHT MOV ASL MOV MON	X #X,RO RO #1,LIGHTS(RO)	;Macro to turn on light X		
.ENDM	PEUN	X			
.MACRO	MON	DISN	;Macro invokes the monitoring		

; subroutine

#DISN,R2 MONSUB

MOV CALL

.ENDM

. MACR	MOV SWAB CALL SWAB CALL MOV CALL CALL	A A,R5 R5 DISEND R5 DISEND #177,R5 DISEND DISEND	;This macro is used to move information to ; the display. ;Send high byte ;Send low byte ;Send two FFH to clear latches
.MACR	MOV MOV CALL	DISN #OFFPOW, POWER #DISN,R2 ADR	;This macro moves the word 'OFF' to the ; display. By looking up the correct number ; in memory.
.MACR	MOV MOV CALL MOV	RO,-(SP) #229.,RO PWAIT (SP)+,RO	;This macro forces a pause with N=229
.MACR	O SHFT4 ASL ASL ASL ASL	X X X X	;This macro shifts left by 4 ; effectively multiplying by 16

.ENDM

```
MAIN PROGRAM
                                 ;Begin with TWT flag off
START:
        CLR
                TWIFLG
                 @#RXCSR
                                 ;Ensure no interrupts
RESTRT: CLR
        CIR
                CMDRDY
                                 ;Fake KBD ready bit
        CLR
                CMDWRD
                                 ;Fake KBD data
        MOV
                 #120000,SP
                                 ;Set up stack in RAM area
        CLR
                R0
        MTPS
                R0
                                 ;Clear processor status
        TSTB
                 @#RXBUF
                                 ;Clear ready bit
        MOV
                                 ;Enable keypad interupts
                 #100,@#RXCSR
MAIN:
        CLR
                LIGHTO
        CIR
                LIGHT1
        CLR
                LIGHT2
        CLR
                 LIGHT3
        CLR
                LIGHT4
        CIR
                RFON
                                          ;TWT RF on flag
        INC
                                          ;Set it for startup monitoring
                RFON
        MOV
                 #1,DSBUF
                                         ;Clear display panel
        MOV
                 #17,0#DISP
        CALL
                 DOBRK
                                          ;Output break to reset display
INIT:
        MDS
                 DSBUF
        ADD
                 #2,DSBUF
        CMP
                 DSBUF, #17
        BLT
                 INIT
        MOV
                 #1,DSBUF
        Begin power monitoring and check for keypad input
MONIT:
        TSTB
                 CMDRDY
                                 ;Keypad hit?
        BMI
                 1$
        JMP
                 TEST
                                 ;No - monitor mode
1$:
        CLR
                 CMDRDY
                                 ;Yes - clear flag
        TST
                 CMDWRD
                                 ; Put in command lookup offset
        BMI
                 2$
                                 ; if CMDWRD=-1 then use previous command
        MOV
                CMDWRD, TABIN
        DARK
2$:
                                 ;Turn off all lights
        DARK
                1
        DARK
                 2
        DARK
                 3
        DARK
        CMP
                TABIN, #16.
        BEQ
                TXSET
        BIT
                 #2,TABIN
        BNE
                TXSET
                RFON
RXSET:
        CLR
                                 ;Receive mode only
        CALL
                SWISET
        CALL
                TWIOFF
        LIGHT
                0
                                 ;Turn on SYSTEM READY light
        JMP
                RXMON
```

TXSET: MOV #1,RFON :Transmit or translate mode CALL SWISET CALL TWION LIGHT 0 ;Turn on SYSTEM READY light JMP TXMON TEST: TST RFON ; Is Tx flag set? BEQ RXMON ;No - Rx monit mode JMP 0#TXMON ;Yes - Tx monit mode RXMON: CALL DOBRK CALL BITCHK OFF ;Display 'OFF' 2 ; in TWT display OFF 3 OFF 4 ; section MON 1 ;Read power MON ; from LO'S JMP @#MONIT ;Loop in monitor mode TXMON: CALL DOBRK CALL BITCHK MON 2 ;Read power MON 3 ; from TWT input MON 4 ; and output MON 1 ;Read power MON 0 ; from LO'S

;Loop in monitor mode

JMP

TIMOM#9

3\$:

RETURN

```
SUBROUTINES
        ADR - determines the address for a data word to the display
                                  ; Address to the BCD information that is
ADR:
        .REPT
                 ASL
                         POWER
                                  ; transmitted to the display.
        .ENDR
                                  :Move left three bits
                R2,R3
        MOV
                                  ; If channel 0, send out to display
        TST
                R3
                                  ; address 5 - change in wiring
        BGT
                 1$
                 #5,R3
        MOV
1$:
                 R3, POWER
        ADD
                                  ;Append the display address to POWER
        ASL
                 POWER
        MOV
                R2,R3
        ASL
                 R3
        ADD
                 LIGHTS (R3), POWER
                                          ;Set light bit
        MDS
                 POWER
        RETURN
        BITCHK - ensures the LIGHT registers reflect the status of the
                  feedback bits
BITCHK: MOV
                 @#FBREG, FBBUF
        CLR
                 LIGHT4
                                  ;Check AC ON
        BIT
                 #WJON, FBBUF
        BEQ
                 1$
        MOV
                 #1,LIGHT4
1$:
        CIR
                 LIGHT3
                                  ;Check READY
        BIT
                 #IWIRDY, FBBUF
        BEQ
                 2$
        MOV
                 #1,LIGHT3
2$:
        CLR
                 LIGHT2
                                  :Check RF ON
        BIT
                 #TWIRF, FBBUF
        BEO
                 3$
        MOV
                 #1,LIGHT2
```

```
CHECK - ensures that the values sampled are within acceptable limits
CHECK: BR
                CHKOK
        CMP
                R2,#4
        BEO
                CHKSWR
        CMP
                R2,#2
        BNE
                CHKOK
                                         :Maximum is -2.0dB
CHKPI:
        CMP
                POWER, #20.
                                         ;Note Pi is negative at display
        BLE
                CHKBAD
        BR
                CHKOK
                                         ; but not in storage
CHKSWR: TST
                OLDPO
                                         ; If no output power, do not check SWR
        BEQ
                CHKOK
                                         :Maximum is 1.50
        CMP
                POWER, #150.
        BGE
                CHKBAD
                CHKOK
        BR
CHKBAD: MOV
                TABIN, R1
        MOV
                LMTBL(R1), LMBUF
        BIC
                #IWIBIT, LMBUF
        MOV
                LMBUF, @#SWREG
CHKOK: RETURN
        DISEND - send byte to display
                @#TXCSR
DISEND: TSTB
                                 ;Send the lower byte of R5 to the serial line
        BPL
                DISEND
        MOVB
                R5, @#DISP
        RETURN
        DOBRK - outputs break to display
DOBRK:
       MOV
                #200.,R0
                                         ;Wait to ensure all characters sent
        CALL
                PWAIT
        BIS
                #1,0#TXCSR
                                         ;Start break
        MOV
                #80.,R0
                                         ;Wait a period
                PWAIT
        CALL
        BIC
                #1,@#TXCSR
                                         ;End break
        MOV
                #200.,R0
                                         ;Wait to ensure line up for stop bits
        CALL
                PWAIT
        RETURN
```

The second seconds second seconds seconds seconds seconds seconds seconds seconds

```
LOOKUP - converts sample count to actual unit values via lookup tables
LOOKUP: CMP
                 R2,#1
         BLE
                 LOLOOK
                                                    ; For channels 0-1, LO lookup
         CMP
                 R2,#2
         BEQ
                 PILOOK
                                                    ; For channel 2, TWT Pi lookup
         CMP
                 R2.#3
         BEO
                 POLOOK
                                                    ; For channel 3, TWT Po lookup
         QMP
                 R2,#4
         BEO
                 PRLOOK
                                                    ;For channel 4, lookup
         JMP
                 SWRCAL
                                                    ; For SWR calc, SWR lookup
LOLOOK: .REPT
                 5
                                   ;Divide by 32
                 ASR
                          R4
         .ENDR
                 #799.,R2
        MOV
         CMP
                 R4,#65.
                 NUMRDY
         BGE
         ASL
                 R4
        MOV
                 LOPWR (R4), R2
        TST
                 R2
         BGE
                 NUMRDY
         CLR
                 R2
NUMRDY: MOV
                 R2,R4
        RETURN
PILOOK: .REPT
                                  ;Divide by 16
                 ASR
                         R4
         .ENDR
        CLR
                 R2
        CMP
                 R4, #65.
        BGE
                 NUMRD2
        ASL
                 R4
                 PIPWR(R4),R2
        MOV
        TST
                 R2
                 NUMRD2
        BGE
        MOV
                 #799.,R2
NUMRD2: MOV
                 R2,R4
        RETURN
POLOOK: .REPT
                 5
                                  ;Divide by 32
                 ASR
                         R4
        .ENDR
        MOV
                 #799.,R2
        GMP
                 R4, #93.
        BGE
                 NUMRD3
        ASL
                 R4
        MOV
                 POPWR(R4),R2
        TST
                 R2
        BGE
                 NUMRD3
        CLR
                 R2
NUMRD3: MOV
                 R2,R4
        RETURN
```

PRLOOK: .REPT ;Divide by 16 ASR R4 .ENDR #799.,R2 MOV R4, #94. CMP NUMRD4 **BGE** ASL R4 MOV PRPWR(R4),R2 NUMRD4: MOV R2,R4 RETURN ;Divide by 8 SWRCAL: .REPT ASR R4 .ENDR MOV #799.,R2 TST R4 BLT NUMRD5 MOV #100.,R2 R4,#64. CMP **BGE** NUMRD5 ASL R4 MOV SWR (R4), R2 TST R2

NUMRD5

MOV #799.,R2 NUMRD5: MOV R2,R4

BGE

RETURN

```
MONSUB - monitoring routine, invoked by macro MON
MONSUB: CLR
                SUMPOW
        CIR
                SUMONT
        MOV
                R2, CHANNO
GETSPL: MOV
                CHANNO, R2
                                         ;Get information from A/D converter
        CALL
                READ
                                         ; and input to the variable power.
        ADD
                R4,SUMPOW
        INC
                SUMONT
        CMP
                SUMCNT, #8.
        BNE
                GETSPL
        MOV
                SUMPOW, R4
                                 ;Once the total of 8 samples is available,
        ASR
                R4
                                 ; average them.
        ASR
                R4
        ASR
                R4
        MOV
                CHANNO, R2
                                 ;Convert raw count to power levels
        CALL
                LOOKUP
        CMP
                CHANNO, #3
        BLT
                DOCHK
                                 ;No more processing on channels 0 - 2
        BEQ
                TWIPO
        BGT
                TWIPR
        MOV
                R4,OLDPO
                                 ;Save the value for later computation on SWR
TWIPO:
        BR
                DOCHK
                OLDPO,R4
TWIPR:
        SUB
                                 ;Find difference between relect and output
        NEG
                R4
                                 ; power in dB.
        MOV
                #5,R2
        CALL
                LOOKUP
                                 ;Convert to SWR
        BR
                DOCHK
DOCHK: MOV
                CHANNO, R2
                                 ;Ensure that the power readings are within
        CALL
                CHECK
                                 ; safe limits.
        BCD
                POWER
                                 ;Take the number in POWER and change it to BCD
        MOV
                CHANNO, R2
        CALL
                ADR
                                 Display the result by appending address bits
        RETURN
                                 ; to the BCD information
        PWAIT - waiting procedure, used between samples and for break
PWAIT:
       CLR
                R3
                                ; Waiting routine. The algorithm used is:
        INC
                R3
                                        T = K(N*N+N)/2
        CLR
                R2
                                        K = speed of ADD instruction
1$:
        ADD
                #1,R2
                                        N = constant to give correct pause
        CMP
                R3,R2
        BNE
                1$
        ADD
                #1,R3
        CLR
                R2
        CMP
                RO, R3
                                ;N is the number to which R3 is compared
        ENE
                1$
       RETURN
```

```
READ - takes readings
; This subroutine gets the A/D converted value of power from a particular
; channel indicated by disn. This is received by the A/D as a DC voltage level
  from microwave detectors.
        R2 contains the channel number
                 0 = 10 \text{ down}
                 1 = 10 \text{ up}
                 2 = Pi to TWT
                 3 = Po of TWT
                 4 = Pr - reflected power from load
        R4 will contain the conversion count
READ:
        MOV
                 #SCALE8,R4
                                                   :Normal scale 8X for
        CMP
                 R2,#3
                                                   ; channels 0-2 and 4
        BNE
                 1$
        MOV
                 #SCALE2,R4
                                                   ; 2X for channel 3
1$:
        BIS
                 #ADGO,R4
                                                   ;Set go bit
        SWAB
                 R2
                                                   ; Move channel number to bit
                                                   ; positions 8-11
        ADD
                 R2,R4
                                                   ;Set channel number
        MOV
                 R4, @#ADCSR
                                                   ;Start conversion and wait
2$:
        TSTB
                 @#ADCSR
                                                   ; for sample
        BPL
                 2$
        MOV
                 @#ADBUF,R4
        RETURN
        SWISET - sets the configurations on the shelf
SWISET: MOV
                 TABIN, R1
                                  ;Get config word
        MOV
                 LMTBL(R1), LMBUF
        BIS
                 TWIFLG, LMBUF
                                  ;OR in TWT bits if they were previously set
        MOV
                 LMBUF, @#SWREG
                                  Drive switches
        BIC
                 #IWIBIT, IMBUF
        MOV
                 #TWTBIT, MASK
        CALL
                 WAITNG
        LICHT
                 1
                                  ;Turn on SWITCHES SET light
        RETURN
        TWTOFF - turns off the TWT unless it should be in standby
TWTOFF: MOV
                 @#FBREG,FBBUF
                                  ;Get actual configuration
        BIT
                 #WJON, FBBUF
        BEQ
                 TWIOK
WASON:
        LIGHT
        TST
                 TWIFLG
                                  ;Should TWT be standby?
        BNE
                 TWTOK
TURNOF: MOV
                 TABIN, R1
                                  ;Get config word
        MOV
                 LMTBL(R1), LMBUF
        MOV
                                 ;Drive switches
                 LMBUF, @#SWREG
        MOV
                 #NOMASK, MASK
        CALL
                WAITNG
        DARK
TWIOK: RETURN
```

Control of the contro

CHARLES SECURE

```
50
        TWTON - turns on the TWT for Tx or translate
TWION:
       MOV
                TABIN, R1
        MOV
                LMTBL(R1), LMBUF
        MOV
                LMBUF, @#SWREG
                                         ;Set for WU & TWT on and RF on
TWUON:
       MOV
                #WJON, LMBUF
                                         ; Mask off everything but WUON bit
        MOV
                #^C<WJON>, MASK
        CALL
                WAITING
        LIGHT
TREADY: MOV
                @#FBREG,FBBUF
                #IWIRDY, FBBUF
        BIT
        BEX
                TREADY
        LIGHT
TRFON: MOV
                #IWIRF, LMBUF
                                         ;Mask off everything but TWTRF bit
        MOV
                #^C<TWIRF>,MASK
        CALL
                WAITNG
        LIGHT
        MOV
                #TWIAC+WJON, TWIFLG
        RETURN
        WAITNG - a subroutine that waits for a switch to be set
                      The subroutine reads the feedback register, MASKs off
                 don't care bits and compares it with IMBUF. It does this
                 a maximum of 60 times with pauses in between. If after
                 these 60 trys, the switches aren't set, the subroutine
                 aborts the setup procedure and jumps into the monitor mode.
WAITING: CLR
                RO
        CMP
                RO,#60.
                                 ;60 tries?
1$:
        BEQ
                TIMOUT
                                 ;Yes - error
        INC
                                 ;Count tries
                RO
        PAUSE
                                 ;Wait for switches to toggle
        MOV
                @#FBREG,FBBUF
                                 ;Read position of switches
        BIC
                MASK, FBBUF
                                 ;Clear bits in mask
        CMP
                FBBUF, LMBUF
                                 ;Switches set yet?
        BNE
                                 ;No - try again
        RETURN
TIMOUT: MOV
                 (SP)+,RO
                                 ;Pop off return address to TWION/OFF or SWISET
                                 ;Pop off return address to RX/TXSET
        MOV
                 (SP)+,RO
                #1,RFON
        MOV
                                 ;Ensure all points are monitored
```

;Return to monitoring but don't change lights

THE PARTY CONTROL OF THE PARTY OF THE PARTY

JMP

TEST

Interrupt routines

,			
KBINTR:	CLR	@#RXCSR	;Disable interrupts
	CLR	TEMP1	
	MOVB	@#RXBUF,TEMPl	;Fake keypad data buffer
	BIC	#200,TEMP1	;Mask off parity bit
	BIT	#1,TEMP1	;Ensure an even numbered key
	BNE	RETINT	
	CMP	TEMP1,#64.	;Validate keys -
	BLT	RETINT	; between 64 and 80
	CMP	TEMP1,#80.	
	BLE	VALKEY	
	CMP	TEMP1,#88.	;GO
	BEQ	GOKEY	
	CMP	TEMP1,#90.	CLEAR KEY
	BEQ	CLRKEY	
	CMP	TEMP1,#94.	;TWI OFF
	BEQ	TWIKEY	
	BR	RETINI	
VALKEY:	:	TEMP1, CMDWRD	
	SUB	#64.,CMDWRD	
	BR	RETINI	
GOKEY:	MOVB		;Fake keypad CSR ready bit
	BR	RETINT	
CLRKEY:		CMDWRD	
	BR	RETINT	
TWIKEY:		TWIFLG	;Turn off TWT with no change to switches
	MOV	#177777,CMDWRD	
	MOVB	#200,CMDRDY	
Demo-	BR	RETINT	Pholila laward inhammen
RETINT:		#100,0#RXCSR	;Enable keypad interrupts
	RTI		

CONSTANT AREAS

IOPWR: ;Lookup table for IO power readings

```
-600.,-60.,-27., -9., 4., 18., 28., 38.
.WORD
           46., 53., 60., 67., 72., 78., 83., 88.
.WORD
.WORD
           92., 97.,101.,105.,109.,112.,115.,118.
          122.,125.,128.,130.,133.,136.,138.,141.
.WORD
.WORD
          143.,146.,148.,150.,152.,154.,156.,158.
.WORD
          160.,162.,164.,166.,168.,170.,171.,173.
          175.,176.,178.,179.,181.,183.,184.,186.
.WORD
          187.,188.,190.,191.,192.,194.,195.,196.
.WORD
.WORD
          198.
```

PIPWR: ;Lookup table for TWT power input readings

```
.WORD
          799.,799.,252.,195.,169.,153.,139.,133.
.WORD
          127.,114.,107.,101., 97., 93., 89., 84.
           81., 78., 75., 73., 70., 67., 64., 62.
.WORD
.WORD
           60., 57., 54., 52., 50., 48., 46., 45.
.WORD
           43., 41., 39., 38., 36., 35., 33., 32.
.WORD
           30., 29., 28., 27., 25., 24., 23., 22.
           21., 19., 18., 17., 16., 15., 14., 13.
.WORD
.WORD
           12., 11., 11., 10., 9., 8., 7.,
.WORD
            0.
```

POFWR: ;Lookup table for TWT power output readings

```
.WORD
            0.,168.,173.,177.,180.,184.,187.,190.
.WORD
          193.,195.,198.,201.,205.,209.,213.,216.
.WORD
          219.,222.,225.,227.,230.,233.,237.,240.
.WORD
          243.,246.,249.,252.,254.,257.,260.,262.
.WORD
          265.,268.,270.,272.,275.,277.,279.,281.
.WORD
          284.,286.,288.,290.,292.,294.,296.,298.
.WORD
          299.,301.,303.,305.,306.,308.,310.,312.
.WORD
          313.,315.,316.,318.,319.,321.,322.,324.
.WORD
          325.,327.,328.,329.,331.,332.,334.,335.
.WORD
          336.,337.,339.,340.,341.,342.,344.,345.
.WORD
          346.,347.,348.,349.,350.,352.,353.,354.
.WORD
          355.,356.,357.,358.,359.
```

PRPWR: ;Lookup table for reflected power

The Control of the Control

```
.WORD
         -999.,-367.,-152.,-95.,-69.,-53.,-39.,-33.
          -27.,-14., -7., -1., 2., 6., 11., 15.
.WORD
.WORD
           18., 21., 24., 26., 29., 32., 35., 37.
.WORD
           39., 42., 45., 47., 49., 51., 53., 54.
           56., 58., 60., 61., 63., 64., 66., 67.
.WORD
.WORD
           69., 70., 71., 72., 74., 75., 76., 77.
.WORD
           78., 80., 81., 82., 83., 84., 85., 86.
.WORD
           87., 88., 88., 89., 90., 91., 92., 93.
           94., 95., 97., 98., 99.,100.,101.,102.
.WORD
.WORD
          103.,104.,105.,105.,106.,107.,108.,108.
.WORD
          109.,110.,111.,112.,112.,113.,114.,115.
.WORD
          116.,116.,117.,118.,118.,119.
```

SWR: ;Lookup table for SWR calculations

```
.WORD
          799.,290.,281.,272.,263.,255.,246.,237.
.WORD
          228.,219.,211.,202.,193.,184.,175.,167.
.WORD
          159.,152.,147.,141.,137.,133.,130.,128.
.WORD
          125.,123.,120.,118.,116.,114.,114.,112.
.WORD
          111.,110.,109.,108.,107.,106.,106.,105.
.WORD
          105.,104.,104.,103.,103.,103.,103.,102.
.WORD
          102.,102.,102.,101.,101.,101.,101.,101.
.WORD
          101.,100.,100.,100.,100.,100.,100.
```

IMTBL: ;Lookup table for switch configurations based on command key

```
LES8+DISH+RX
.WORD
.WORD
        LES8+DISH+TX
.WORD
        LES8+HORN+RX
.WORD
        LES8+HORN+TX
.WORD
        LES9+DISH+RX
.WORD
        LES9+DISH+TX
.WORD
        LES9+HORN+RX
.WORD
        LES9+HORN+TX
```

.WORD LES8+DISH+TX+TRANLA

RAM AREA FOR VOLATILE MEMORY LOCATIONS

= START+77000

.END START

UNCLASSIFIED

		Security Classification				
OCUMENT CONTR (Security classification of title, body of abstract and indexing a						
ORIGINATING ACTIVITY Communications Research Centre under t	he CRAD	2a. DOCUMENT SECURITY CLASSIFICATION UNCLASSIFIED				
sponsored program of recoverable resear	rch.	26 GROUP				
3 DOCUMENT TITLE						
EHF Shelf Monitor and Controller						
4 DESCRIPTIVE NOTES (Type of report and inclusive dates)						
5. AUTHOR(S) (Last name, first name, middle initial)						
R. Addison						
6. DOCUMENT DATE SEPTEMBER 1985	7a. TOTAL NO	O OF PAGES 76. NO. OF REFS				
8a. PROJECT OR GRANT NO	9a. ORIGINAT	TOR'S DOCUMENT NUMBER(S)				
32A53						
8b. CONTRACT NO.	9b. OTHER DOCUMENT NO (S) (Any other numbers that may be assigned this document)					
10. DISTRIBUTION STATEMENT						
Unlimited						
						
11. SUPPLEMENTARY NOTES	12. SPONSORING ACTIVITY					
	Delence P	Research Establishment Ottawa				
13. ABSTRACT	*··					
In 1981 CRAD sponsored the development of an experimental 36/38 GHz satellite communications ground terminal in order to permit further experimental work with the Lincoln experimental satellites (LES 8/9). Due to the physical separation of the RF and antenna installation from the IF and baseband equipment, it was desired to have a remote control and monitor facility for the ground terminal. This subsystem is described in this report.						

DSIS

UNCLASSIFIED

Security Classification

KEY WORDS

EHF

MONITOR

CONTROLLER

INSTRUCTIONS

- ORIGINATING ACTIVITY: Enter the name and address of the organization issuing the document.
- DOCUMENT SECURITY CLASSIFICATION. Enter the overall security classification of the document including special warning terms whenever applicable.
- GROUP: Enter security reclassification group number. The three groups are defined in Appendix 'M' of the DRB Security Regulations.
- DOCUMENT TITLE: Enter the complete document title in all capital letters. Titles in all cases should be unclassified. If a sufficiently descriptive title cannot be selected without classification, show title classification with the usual one-capital-letter abbreviation in parentheses immediately following the title:
- 4. DESCRIPTIVE NOTES. Enter the category of document, e.g. technical report, technical note or technical letter. If appropriate, enter the type of document, e.g. interim, progress, summary, annual or final. Give the inclusive dates when a specific reporting period is covered.
- AUTHOR(S): Enter the name(s) of author(s) as shown on or in the document. Enter last name, first name, middle initial.
 If military, show rank. The name of the principal author is an absolute minimum requirement.
- 6. DOCUMENT DATE Enter the date (month, year) of Establishment approval for publication of the document
- TOTAL NUMBER OF PAGES The total page count should follow normal pagination procedures, i.e., enter the number of pages containing information.
- 7b. NUMBER OF REFERENCES: Enter the total number of references cited in the document.
- 8a. PROJECT OR GRANT NUMBER: If appropriate, enter the applicable research and development project or grant number under which the document was written.
- 8b. CONTRACT NUMBER If appropriate, enter the applicable number under which the document was written.
- 9a. ORIGINATOR'S DOCUMENT NUMBER(S): Enter the official document number by which the document will be identified and controlled by the originating activity. This number must be unique to this document.

- 9b. OTHER DOCUMENT NUMBER(S): If the document has been assigned any other document numbers (either by the originator or by the sponsor), also enter this number(s).
- DISTRIBUTION STATEMENT: Enter any limitations on further dissemination of the document, other than those imposed by security classification, using standard statements such as.
 - (1) "Qualified requesters may obtain copies of this document from their defence documentation center."
 - (2) "Announcement and dissemination of this document is not authorized without prior approval from originating activity."
- 11. SUPPLEMENTARY NOTES: Use for additional explanatory
- SPONSORING ACTIVITY Enter the name of the departmental project office or laboratory sponsoring the research and development. Include address.
- 13. ABSTRACT: Enter an abstract giving a brief and factual summary of the document, even though it may also appear elsewhere in the body of the document itself. It is highly desirable that the abstract of classified documents be unclassified. Each paragraph of the abstract shall end with an indication of the security classification of the information in the paragraph (unless the document itself is unclassified) represented as (TS), (S), (C), (R), or (U).

The length of the abstract should be limited to 20 single-spaced standard typewritten lines, $7^{\rm t}_{\rm T}$ inches long.

14. KEY WORDS: Key words are technically meaningful terms or short phrases that characterize a document and could be helpful in cataloging the document. Key words should be selected so that no security classification is required. Identifiers, such as equipment model designation, trade name, military project code name, geographic location, may be used as key words but will be followed by an indication of technical context.

12-86

07/